Print this Page

CHEVROLET

MODEL			YEAR(S)		
IMPALA			2006 -2008		
KEY	T-HARNESS	ON NO. DA OO		IMMOBILIZER	
N/A N/A		GM'S PASSKEY 3+ requires PKUGN COLOR		LOCATION	
PART 12 VOLT CONSTANT		RED/WHITE (+)		@ IGNITION HARNESS or BCM,	
		• •		BLUE Plug, Pin 3, See NOTE *1	
STARTER		YELLOW (Not for Remote Starting)		@ ECM, See NOTE *2	
STARTER 2		N/A			
IGNITION 1		PINK (+)		@ IGNITION HARNESS or BCM, GREEN Plug, Pin 14, See NOTE *1	
IGNITION 2		N/A			
IGNITION 3		N/A			
ACCESSORY/HEATER BLOWER 1		BROWN (+)		@ IGNITION HARNESS or BCM, GREEN Plug, Pin 21, See NOTE *1	
ACCESSORY/HEATER BLOWER 2		N/A			
KEYSENSE		N/A			
PARKING LIGHTS (-)		BROWN/WHITE (-)		@ HEADLIGHT SWITCH or BCM, WHITE Plug, Pin 8, See NOTE *1	
PARKING LIGHTS (+)		PURPLE (+) LEFT and BROWN/WHITE (+) RIGHT, USE BOTH wires, will require (2) extra Relays, See DIAGRAM		in PASSENGER KICK Panel, Harness to Rear of Vehicle.	
POWER LOCK		ORANGE/BLACK (TYPE B)		IN DRIVER KICK PANEL or BCM, GRAY Plug, Pin 12, See NOTE *1	
POWER UNLOCK		ORANGE/BLACK OR PINK/BLACK (TYPE B)		IN DRIVERS KICK PANEL or BCM, GRAY Plug, Pin 11, See NOTE *1	
DOOR TRIGGER		See NOTE *4		IN EACH KICK PANEL or BCM, PINK Plug, See NOTE *1	
DOMELIGHT SUPERVISION		GRAY/BLACK (+)		IN DRIVERS KICK PANEL or BCM, PINK Plug, pin 1, See NOTE *1	
TRUNK RELEASE		LIGHT BLUE (-)		@ TRUNK RELEASE SWITCH or BCM, WHITE Plug, Pin 10, See NOTE *1	
SLIDING POWER DOOR		N/A			
HORN		TAN (-)		@ HORN SWITCH or BCM, BROWN Plug, Pin 18, See NOTE *1	
TACH		NOT PINK/BLACK		@ Any FUEL-INJECTOR	
WAIT TO START LIGHT		N/A			
BRAKE		LIGHT BLUE (+)		IN DRIVERS KICK PANEL or BCM, PINK Plug, Pin 22, See NOTE *1	
FACTORY ALARM DISARM		FACTORY REMOTE ONLY			
ANTI-THEFT		PASSKEY 3 (PK3) TRANSPONDER		@ IGNITION SWITCH TUMBLER	
		EXTRA	INFORMATION		

1 of 2 2/18/2009 10:16 PM

NOTE *1 The BCM (Body Control Module) is located to the LEFT of the Steering Column. NOTE *2 THIS VEHICLE HAS A SPECIAL IGNITION SWITCH THAT REQUIRES A PKUGM2X FOR REMOTE STARTING. The ECM (Engine Control Module) is located behind the Drivers Side Headlight, in the Air Cleaner Assembly. NOTE *3 There is a WHITE wire and a WHITE/BLACK wire in the IGNITION HARNESS or the BCM, GREEN Plug, Pins 2 and 4 that work as the Starter, and Second Ignition, See DIAGRAM NOTE *4 The DRIVERS DOOR is a GRAY/BLACK (-) Pin 10, the PASSENGER DOOR is a TAN/WHITE (-) Pin 8, the DRIVERS REAR DOOR is a BLUE/BLACK (-) Pin 15 and the PASSENGER REAR DOOR is a LIGHT GREEN/BLACK (-) Pin 14, when connecting to an Alarm System, use all (4) wires and Diode Isolate.

2 of 2 2/18/2009 10:16 PM